



Kata - Pulse Wave & Vibrating Double Penetration Vibrator - Black

Product Information

Item number	VIVE034BLK
EAN code	7423522538548
Brand name	VIVE by Shots



Instructions for use

Product Overview

Thank you for choosing the Kata - Pulse Wave & Vibrating Double Penetration Vibrator - Black. This innovative device is designed to enhance your intimate experiences with its unique features, providing both pulse wave and vibrating sensations.

Components

- Main Body: The core unit that houses the motor and controls.
- Dual Penetration Arms: Designed for simultaneous stimulation.
- Control Buttons: Located on the main body for easy operation.

Charging Instructions

1. Connect the Charger: Insert the charging cable into the designated port on the main body.
2. Power Source: Plug the other end into a USB power source.
3. Charging Indicator: A light will illuminate to indicate that the device is charging.
4. Full Charge: Allow the device to charge completely before first use for optimal performance.

Operating Instructions

1. Power On: Press and hold the power button located on the main body until the device turns on.
2. Mode Selection: Use the additional buttons to cycle through various pulse wave and vibration modes. Experiment to find the combination that best suits your preferences.
3. Adjust Intensity: Adjust the intensity of the vibrations and pulse waves to your desired level using the control buttons.
4. Power Off: Press and hold the power button again until the device shuts down after use.

Usage Guidelines

- Lubrication: Apply a water-based lubricant to enhance comfort and pleasure.
- Insertion: Gently insert the dual penetration arms as desired. Ensure you are comfortable and relaxed.
- Experiment: Explore different modes and intensities to discover what feels best for you.

Cleaning and Maintenance

1. Turn Off: Ensure the device is powered off before cleaning.
2. Clean: Use warm water and mild soap or a toy cleaner to clean the surface of the vibrator.
3. Dry: Pat dry with a clean, dry cloth.
4. Storage: Store in a cool, dry place away from direct sunlight.

Safety Precautions

- Do not submerge the device fully in water.
- Avoid using the device on swollen or inflamed areas.
- Discontinue use if you experience any discomfort or irritation.
- Keep out of reach of children.

By following these instructions, you can ensure a satisfying and safe experience with your Kata - Pulse Wave & Vibrating Double Penetration Vibrator - Black. Enjoy your journey to enhanced pleasure and satisfaction.



Washing instructions

To ensure the longevity and hygiene of your Kata - Pulse Wave & Vibrating Double Penetration Vibrator, please follow these cleaning instructions:

1. Before Use: Always wash the vibrator before your first use.

2. Cleaning:
 - Rinse the vibrator under warm water.
 - Use a mild, unscented soap or a dedicated toy cleaner to gently wash the surface.
 - Make sure to clean all areas, including any textured or ridged parts.
3. Rinsing: Thoroughly rinse the vibrator with warm water to remove any soap residue.
4. Drying:
 - Pat the vibrator dry with a clean, soft towel.
 - Allow it to air dry completely before storing.
5. Storage: Store your vibrator in a cool, dry place away from direct sunlight and extreme temperatures. Avoid contact with other toys to prevent material degradation.

Important Note: Do not submerge the vibrator in water or place it in the dishwasher. Avoid using harsh cleaners or alcohol-based products, as they can damage the material.

By following these instructions, you will help maintain the quality and safety of your Kata - Pulse Wave & Vibrating Double Penetration Vibrator for many enjoyable experiences.

Ingredients

-

Warnings

Before using the Kata - Pulse Wave & Vibrating Double Penetration Vibrator, please read the following important safety information:

1. Intended Use: This product is designed for adult use only. Ensure you are of legal age and fully understand its intended purpose.
2. Health Considerations: Individuals with heart conditions, sensitive skin, or those who are pregnant should consult a healthcare professional before use. Discontinue use if you experience any discomfort or adverse reactions.
3. Lubrication: For optimal enjoyment and comfort, it is recommended to use a water-based lubricant. Avoid using oil-based or silicone-based lubricants, as they may damage the product.
4. Hygiene: Clean the vibrator thoroughly before and after each use with a mild soap and warm water or a suitable toy cleaner. Ensure the product is completely dry before storing.
5. Battery Safety: If the product requires batteries, follow all instructions regarding battery installation and disposal. Do not mix old and new batteries, and remove batteries when not in use for extended periods.
6. Electrical Safety: If the vibrator is rechargeable, ensure it is charged according to the manufacturer's instructions. Do not use the product while it is charging. Avoid exposing the device to water or extreme temperatures.
7. Use Caution: This product is intended for consensual use only. Communicate openly with your partner(s) about comfort levels and boundaries.
8. Storage: Store the vibrator in a cool, dry place, away from direct sunlight and extreme temperatures. Keep it out of reach of children and pets.

By using the Kata - Pulse Wave & Vibrating Double Penetration Vibrator, you acknowledge that you have read and understood these warnings and agree to use the product responsibly. Enjoy safely!

Disposal instructions

Thank you for choosing the Kata - Pulse Wave & Vibrating Double Penetration Vibrator. When it's time to dispose of your product, please follow these guidelines to ensure safe and environmentally friendly disposal:

1. Clean the Product: Before disposal, ensure that the vibrator is thoroughly cleaned. Use a mild soap and water solution to wipe down the exterior. Avoid submerging the product in water.
2. Remove Batteries: If your product uses batteries, please remove them before disposal. Batteries should be disposed of according to local regulations. Many communities have battery recycling programs.
3. Check Local Regulations: Disposal requirements may vary by region. Check with your local waste management authorities for specific guidelines on the disposal of electronic items and personal care products.
4. Recycling: If possible, recycle the vibrator's components. Look for recycling symbols on the packaging and product. Dispose of any recyclable materials in the appropriate recycling bins.
5. Landfill Disposal: If no recycling options are available, the product can be disposed of in the regular trash. Ensure it is placed in a secure bag to prevent any accidental activation.
6. Environmental Considerations: Please be mindful of the environment when disposing of your product. Avoid littering and consider using eco-friendly disposal methods whenever possible.

Thank you for taking the time to dispose of your Kata - Pulse Wave & Vibrating Double Penetration Vibrator responsibly!