

unihorn[®]

Mount'n Peak

START & STOP BUTTONS:
HOLD FOR 2 SECONDS

 FOR MAW PLEASURE
 TO RIDE THE VIBES

SINGLE CLICKS FOR
VARIATIONS OF EACH

unihorn[®]
It's Time To Give In To The Legend!

unihorn[®]


unihorn[®]
It's Time To Give In To The Legend!

unihorn[®]
It's Time To Give In To The Legend!

When it comes to pleasure, everyone has their own individual peak, and this heavenly vibe is sure to find yours. From its sensuous soft body to its deliciously swirling tongue, this enchanting steed has everything you need to take you from teasing to thrilling in just a few buttons.



 @unihornofficial



Peek at my profile & scan to see my teasingly twirling tongue



TEASINGLY
TWIRLING
TONGUE

Mount'n Peak
MAGICAL, DREAMLIKE MINI UNICORN VIBE

- SUPER SOFT BODY SAFE SILICONE
- SUPER POWERFUL
- 20 MIX 'N' MATCH PLEASURE SETTINGS
- WATER RESISTANT
- DELUXE DUAL MOTOR

Create real magic by combining enticing tongue action layered with teasing vibration

CE

IPX6

ROHS COMPLIANT

ISO 3533:2021





5 037353 007474

© Creative Conceptions Ltd 2022. Newark UK. NG24 2AG. Distributed in US & Canada by Creative Conceptions LLC, 42 Reads Way, New Castle DE19720 USA. Made in China.



HOW TO USE

HOW TO USE:

1. Ensure your Unihorn is clean and fully charged before use, using the charging cable provided. During charge the light will blink. Once fully charged the light will remain on.
2. To start the Unihorn's unique mouthpiece, press and hold the  button for 2 seconds. Click to progress through 10 different modes to find your perfect pleasure spot.
3. For even more magic, press and hold the  button for 2 seconds to activate the dual motor within the body. Click to progress through 10 different settings to find your own unique sweet spot.
4. Press and hold both buttons for 2 seconds to turn off.

NOTE:

If using this toy with a lubricant, please use a water-based brand.