


DOXY | BULLET

LET'S GET IT ON

Welcome to your Doxy Bullet

Your Doxy Bullet has 2 speeds, 5 pulse modes and a rechargeable battery.

This page shows you how to use your Doxy Bullet, including selecting modes and recharging the battery.



SELECTING A MODE

- 7 functions (2 speeds + 5 pulses)
- Hold the on/off button for 1-2 seconds to turn on the product, product will rotate at Mode 1: 50% speed. And the LED on.
- Then press the on/off button to change the mode to Mode 2 – Mode 3 – Mode 4 – Mode 5 – Mode 6 – Mode 7. Total 7 functions. LED light works with the rhythm.
- Hold the on/off button for 1-2 seconds to turn off the product, and the LED light off.

Mode 1: 50% speed

Mode 2: 100% speed

Mode 3:



Mode 4:



Mode 5:



Mode 6:



Mode 7:



RECHARGING THE BATTERY

Use the USB cable that came with your Doxy Bullet. Line up the two magnetized metal dots on your charger with the two metal dots on your Doxy Bullet, the white LED light blinks during charging and gives a steady glow when full charged.