

HUE017

Hueman Tapping Butt Plug

Instructions for Use

- **Charging:** Fully charge the device using the provided USB cable before first use.
- **Application:** Apply a water-based lubricant to the plug. Gently insert the plug into the anus.
- **Operation:** Press the power button to cycle through the vibration settings.
- **Cleaning:** After use, clean the plug with warm water and a toy cleaner. Ensure it's completely dry before storage.

Safety Warnings

- Ensure the device is fully charged before use to prevent interruptions.
- Do not use the product while charging.
- Avoid using the ring for extended periods to prevent potential discomfort or injury.
- Keep out of reach of children.
- Store in a cool, dry place away from direct sunlight.
- Use only as intended.