


# BOOTY SPARKS™

## Silicone Vibrating Rose Anal Plug w/ Remote Control

### Use Instructions

1. Press and hold  button on plug to power on/off. Press repeatedly to cycle through 7 patterns of vibration.



\*Plug must be powered on separately. Remove plastic tab from remote battery before use.

### Care Instructions

Use with water-based lubricant. Wash with warm water and toy cleaner after each use. Pat dry and store in a cool, dry location, away from direct sunlight and separated from other toys.

### Charging

Plug jack pin into DC dimple at base of plug and connect to USB port or adapter. Power button flashes while charging. Remove from charger promptly once fully charged.

### Product Information

**Material:** Silicone, ABS plastic

**Voltage:** 3.7V

**Charging time:** 1.3 hours

**Waterproof:** IPX5

**Running time:** 50 minutes

**Remote battery:** 1xCR2032 (included)

**Functions:** 4 speeds + 7 patterns of vibration

**Remote distance:** 32 feet

**Battery type:** Lithium battery

**Lubricant compatibility:** Water-based