

Material: Silicone

Maintenance and Usage Instructions:

- Clean the product with warm water and soap, or toy cleaner before and after use.
- If the product is used daily, clean thoroughly before using vaginally.
- Use caution when cleaning vibrating or motorized products. Moisture in the battery compartment can cause malfunction.
- Apply a sufficient amount of lubricant to the surface of the product before use. Avoid applying lubricant to the controller of vibrating or motorized products, as this can cause malfunction.
- Only use a water-based lubricant unless otherwise specified. Oil-based lubricants may damage certain materials.
- Thoroughly read and follow any instructions listed on/in the packaging of the product before use.
- For pump and/or suction products, be sure to familiarize yourself with the air release feature on your product before use.
- Do not use force with your product.
- Keep the product in a clean, cool and dry place. Do not expose to direct sunlight.
- Keep the product separated from other products made with different materials to avoid any chemical reactions.
- Be sure product is fully inserted before activating.
- Be sure product is turned off before removing.
- Allow vibrating or motorized products to cool down after use and before storing.
- Make sure to use the charging cord provided with your product. Using any other charger may cause malfunction.
- Do not force charging cord into product.
- Make sure to charge product using a USB wall charger. Charging your product using a computer or laptop will result in longer charging times, and/or malfunction.
- Do not charge your product in or around water.

General Warnings and Advice:

- Keep out of reach of children.
- Do not use product in areas where the skin is irritated, broken, and/or infected.
- Do not share products with others.
- Carefully read the description of materials on the package to avoid allergic reactions (e.g. latex).
- If you experience irritation or pain during use, stop use immediately.
- Do not heat/cool the product except where expressly recommended to do so.
- Do not excessively or forcefully bend or stretch the product.
- The product is not intended for commercial use or for any therapeutic purpose.
- This product is intended for use as non-medical pleasure device only.
- For external use only. Any product use for medical purpose or for a use that has an adverse effect on any function of the body is prohibited.
- Do not get non-waterproof products wet, as this may cause malfunction.
- For waterproof products, make sure the battery compartment is securely closed prior to use.
- The product may overheat, turn it off immediately and let it cool before renewed use.
- Do not throw products and/or batteries into a fire.
- The supplier is not liable for the improper use of the product.
- Read all instructions carefully before use.

Environmental Safety:

Please recycle your product packaging material. Products no longer used should be taken to your local household hazardous waste disposal facility in accordance with your national/local recycling regulations and the directives 2002/96/EC and 2006/66/EC. Any product with a crossed out waste bin symbol () indicates this product must be disposed of at a local hazardous waste collection point or an authorized recycling facility.