

# FRONT

# THRiTTiRiNG




COCK ORNAMENT WITH CLIT STIMULATOR



Raccolta differenziata dei rifiuti.  
Controlla le linee guida del tuo comune.



IR00812E-000



Size : 150mm(W) x 100mm(H)

# BACK

## Warnings and Disclaimers:

- To recharge the device, please only use the USB cable that we have provided in the packaging;
- This product is intended for use when supplied with power from the designated battery or power supply unit. Other usage may be dangerous and will invalidate any approval given to this product;
- Please recharge the device for 3 hours before initial usage;
- Do not short the terminals. Connection to improper grounded equipment can result in short-circuit.
- Use of non-original manufacturer-approved accessories will damage the product and cause explosion;
- Recharge the product at room temperature (21°C or 69.8°F);
- Store in a cool and dry place;
- If the device is soiled, clean with a soft cloth;
- Unplug from the socket when the device is not being recharged;
- Keep the device away from fire;
- Keep the device out of reach of infants or children;
- Do not expose the device to any mechanical shock.

## Safety Precautions:


Device will get warm after prolonged use

- The product will get warm after being used for a period of time;
- It is highly recommended to turn the product off and let it cool down before using it again;
- The product should be placed away from heat sources such as radiators, registers, stoves, or other products (including amplifiers) that produce heat.

## Main Compositions: Silicone, ABS Plastic

**Caution:** This product is not intended for therapeutic purposes. It should not be used on swollen or inflamed areas of skin lacerations. Prolonged and frequent use are not advised or recommended as this product is sold as novelty purpose only. This product should be used with discretion. No medical claims are warranted or implied by the use of this product. This product cannot provide water resistance in the bath or in the pool. Splash resistance can be provided only in the shower or during cleaning.

## 10 DYNAMIC RHYTHMS



## How to Operate the Stimulator:

### VIBRATING ON/OFF BUTTON

- Long press the button to turn ON/OFF the device.
- Press shortly to cycle through the 10 dynamic rhythms.



## Technical Data:



OPERATING TEMPERATURE	: 4°C - 60°C
CHARGING VOLTAGE	: 5V
BATTERY	: Li-Ion 3.7V, 0.81Wh
BATTERY CAPACITY	: 220mA
FULLY CHARGED	: Approx. 90 minutes
CHARGING CYCLES	: Approx. 500 times
USAGE PERIOD	: Approx. 60 minutes
INTERFACE	: USB port (5V, >1A)

## Charging Instructions:

\*Ensure that both charging points connect to each other perpendicularly.  
\*Plugging the USB cable incorrectly will cause damage to the device.

Align and connect the magnetic charging point of the cable to the magnetic charging point of the device perpendicularly.

Connect the USB cable into the USB port of the mobile charger or any USB adaptor(s).



- The LED light will start flashing when the device is charging.
- The LED light will keep turning on when the device is fully charged.

## WARNING:




Please DO NOT use the device when it is being charged.



Don't get the device wet while it is being charged.



Please ensure that both charging points connected and DO NOT shake the cable when the device is charging.



DO NOT touch any metal items when the device is charging.