

LOVE BUNNY™ BEADED "G" BUNNY



FEATURES:

- Over 100 combinations of thrusting beads and flickering pleasure
- 12 functions of up and down beaded motion and vibration in the perfectly curved ridged "G" shaft
- 12 functions of vibration, pulsation and escalation in the bunny
- Triple motors with independently operated shaft and stimulator
- Body-safe Silicone and 100% waterproof
- State-of-the-art memory chip resumes on last function used
- Security travel lock feature – hold for 3 seconds to turn on or off
- USB rechargeable – charging cord included
- Complete charge in 2 hours
- Runs for 45 minutes on high speed and 60 minutes on low speed



SILICONE



WATERPROOF
IPX7



TRIPLE
motors



USB
RECHARGEABLE

MATERIALS: Silicone (massager, buttons) ABS with PU cote (décor)

MEASUREMENTS:

4.25" x 1.25"/10.75 cm x 3.25 cm (shaft)

2.5" x 1"/6.25 cm x 2.5 cm (stimulator)

7.5" x 1.25"/19 cm x 3.25 cm (overall)

CHARGING INFORMATION:

LED light will flash while charging and glow solid when fully charged. Fully charge product before use. Battery life depends on frequency and speed of use. We recommend fully charging your product once every 6 months. Complete charge time: 2 hours; Run time on high: 45 minutes; Run time on low: 60 minutes.

OPERATING INSTRUCTIONS:

1. This item comes with a security lock feature. To unlock product, press and hold the power button for 3 seconds to activate; a glowing LED light will indicate the massager is activated.
2. Press the function button to activate vibrations in the stimulator.
3. Press the function button repeatedly until the desired function is reached.
4. To turn off vibrations, press and hold the function button for 3 seconds.
5. To activate shaft functions, press the power button once. Continue pressing the button until the desired function is reached.
6. To turn product completely off, repeat step 1.
7. This item comes with a memory feature; item will resume on last function used.

Product Safety Information

This product is designed for personal, external and/or internal stimulation. Do not use for any other purpose.

Intended for adult use only. Keep out of reach of children and pets.

Only use the USB charging cable provided.

Discontinue use if irritation, discomfort, or pain occurs.

Use only water-based lubricants. Do not use silicone-based lubricants, as they may damage the silicone surface.

Wash before and after use. Do not use harsh chemicals.

Store in a cool, dry place away from direct sunlight.