

EUPHO SYN V

QUICK START

REMOTE CONTROL



Press and hold the multifunction button 2 seconds to turn the remote power on.

*Note, the Eupho Syn V must be turned on manually for the remote to connect to it.

Pressing and holding the button thereafter for 2 seconds will turn both the remote and the Eupho Syn V off.

On power-up the remote is in ready mode and 00 is displayed. Press right arrow or left arrow to choose from 10 patterns.

Intensity (Motor Speed) Selection

Single click the multifunction button to select 4 motor speeds:

Speed one: 10% Speed two: 20% Speed three: 40% Speed four: 100%

DEVICE

Click the multifunction button twice to turn the Eupho Syn V on. You will notice the LED indicator is blinking, this is standby/ready mode.



Pattern Selection

From standby mode, single click multifunction button to advance to vibration patterns 1 though 10. (LED will stop blinking and remain lit when Eupho Syn V is vibrating)

Intensity (Motor Speed) Selection

Depress and hold multifunction button 2 seconds to change to one of four motor speeds:

Speed one: 10% Speed two: 20% Speed three: 40% Speed four: 100%