

DOC JOHNSON®

Available in classic lifelike and non-anatomical shapes, plus a series molded directly from the bodies of the all-time hottest porn stars, Doc Johnson's Main Squeeze features a suction-adjusting end cap, snug textured interior in lifelike ULTRASKYN, and user-controlled squeeze plate, making it the most stimulating and discreet hard-case stroker on the market.



MAINSQUEEZE™

MANSQUEEZE™

• VARIABLE PRESSURE •  
ULTRASKYN™ STROKER

## USAGE AND CARE

### Preparing Main Squeeze for Use

Remove your new Main Squeeze variable pressure stroker from the plastic bag and disassemble it to remove any additional packaging materials from the ULTRASKYN tunnel and other parts.

Package contents may settle during transportation. When reassembling Main Squeeze, make sure the groove in the ULTRASKYN insert aligns with the top edge of the case, and the molded entry point is convex above the case.

*Unpowdered ULTRASKYN, like the clear tunnel used in the OPTIX model, has a naturally sticky feel. It's safe to use this way, but you may wish to clean the ULTRASKYN tunnel before use; see Care & Maintenance page for cleaning instructions and more information.*

ULTRASKYN warms to body temperature with use and can be warmed using the Main Squeeze Warming Accessory (sold separately). Users may also remove the ULTRASKYN tunnel from the case, immerse in warm water to heat, shake off excess water, and reinsert into the case.



*To use the Pop-Off open-ended model, which is designed to penetrate all the way through, remove both caps and follow instructions above.*

### Using Main Squeeze

Apply the water-based lubricant of your choice to your penis and the opening of the ULTRASKYN tunnel. (You may need to self-stimulate to become erect enough to penetrate the opening of the ULTRASKYN tunnel.)

Stroke up and down the shaft of the penis, using the built-in squeeze plate to apply pressure wherever and whenever you choose.

The end cap of the Main Squeeze can be adjusted to create an airtight seal for a stronger or gentler suction effect. For best results, open end cap, insert penis into ULTRASKYN tunnel, and adjust end cap to the preferred suction intensity.



### To Use Vibro with the Vibrating Bullet

(5100-05-BX model)

Before first use, open battery cases of bullet and remote, and remove paper battery-saver tabs.

**Wireless Remote** uses 1 CR2032 battery (included)

**Waterproof Bullet** uses 4 LR44 cell batteries (included)

Disassemble Main Squeeze according to the instructions.

Twist vibrating bullet to On position; vibration will not begin yet.


Locate the opening on the side of Vibro's ULTRASKYN insert and gently stretch it around the vibrating bullet, while pressing bullet into the pocket lengthwise toward the top of the insert.

Reassemble Main Squeeze according to the instructions, positioning the bullet under the squeeze plate or another area according to your preference.

**Press and hold**  on wireless remote to activate vibrating bullet.

**Press**  without holding to cycle through the bullet's vibrating modes.

**Press and hold**  again to power off vibrations.



Disassemble Main Squeeze, remove vibrating bullet using the attached loop, and twist to Off position to avoid draining the battery. Store separately from other toys when not in use.

### Care & Maintenance for Main Squeeze

**To disassemble**, gently pull from the top to remove the ULTRASKYN stroker tunnel from inside the case. Remove squeeze plate from its magnetic lock, or from inside of case if it falls in.

**Wash each section** with Main Squeeze Toy Cleaner\* or mild soap and warm water and allow to air dry completely before storage/reassembly. A stickier texture is normal when ULTRASKYN is clean and unpowdered. This is its natural texture and does not mean your product is defective.

**Dust the ULTRASKYN section** with Main Squeeze Refresh Powder\*, reassemble Main Squeeze, and store in a cool, dry place with both caps on.

*\* When using the clear OPTIX model, skip this step to maintain the appearance of the clear ULTRASKYN insert. Powdering will not damage OPTIX, but will result in a non-sticky frosted appearance.*

**To reassemble after cleaning**, return squeeze plate to its magnetic dock inside the case. Gently press down and twist the ULTRASKYN insert into the case until it returns to its original position. Replace caps at each end, and store in a cool, dry place.

\* Main Squeeze Toy Cleaner and Refresh Powder sold separately.



For warranty information and product registration, please visit us online at [docjohnson.com](http://docjohnson.com)

Copyright © 2018 Doc Johnson Enterprises  
INS-5200-05

Socialize  
with the Doc

[www.docjohnson.com/social-media](http://www.docjohnson.com/social-media)

