

CARE

- * Turn off device when not in use.
- * Do not operate the device while charging.
- * Please follow the charge times indicated in the device specifications.
- * Wash after each use with liquid anti-bacterial soap and water.
- * Pat dry with a cotton towel and allow to air dry completely.

Product Dimensions: 7.8 x 3.82 x 1.54 (in)

IPX Rating: IPX7 Waterproof 30 min. immersion 3 ft.

Battery: Rechargeable

Charge Time: Do not exceed 180 minutes

Run Time: 60 minutes

Modes: 20

SECRETS

FORTE VIBRATING RABBIT




For warranty information, latest products, and news visit us at:

nsnovelties.com

PLAY

- * Press & hold the top button for 2 seconds to power shaft vibration on/off.
- * Quick press the top button to cycle through the shaft speeds/functions.
- * Press & hold the bottom button for 2 seconds to power clitoral vibration on/off.
- * Quick press the bottom button to cycle through the clitoral speeds/functions.



CHARGE

- * The light will blink while the device is charging.
- * The light will become solid once the device is fully charged.

