

RUMBLER RUMBLE WAND



FEATURES:

- Rumbling dual ended massager with flexible head and contoured “G”
- Rippled shaft and head for added sensations
- 10 speeds of intense vibration
- Independently operated dual motors on either end
- Body-safe Silicone and waterproof IPX7 – submersible
- State-of-the-art memory chip resumes on last speed used
- Security travel lock feature – hold for 3 seconds to turn on or off
- USB-C rechargeable – charging cord included
- Complete charge in 1.75 hours
- Runs for 45 minutes on high speed and 80 minutes on low speed



MATERIALS: Silicone

MEASUREMENTS:

9.5” x 2”/24.25 cm x 5 cm

CHARGING INFORMATION:

LED light will flash while charging and glow solid when fully charged. Fully charge product before use. Battery life depends on frequency and speed of use. We recommend fully charging your product once every 6 months. Complete charge time: 1.75 hours; Run time on high: 45 minutes; Run time on low: 80 minutes.

OPERATING INSTRUCTIONS:

1. This item comes with a security travel lock feature.
2. To activate vibration in the massager head, press and hold the button nearest that end for 3 seconds; a glowing LED light will indicate the massager is activated.
3. Press the button repeatedly until the desired speed is reached.
4. To turn off vibration in the massager head at any time, repeat step 2.
5. To activate vibration in the Contoured “G”, press and hold the button nearest that end for 3 seconds; a glowing LED light will indicate the Contoured “G” is activated.
6. Press the button repeatedly until the desired speed is reached.
7. To turn off vibration in the Contoured “G” at any time, repeat step 5.
8. This item comes with a memory feature; item will resume on last speed used.