

## RAVE BUNNY



### FEATURES:

- Dual massager with rippled shaft and teasing bunny ears
- 10 speeds of intense vibration
- Body-safe Silicone and 100% waterproof
- State-of-the-art memory chip resumes on last speed used
- Security travel lock feature – hold for 3 seconds to turn on or off
- USB rechargeable – charging cord included
- Complete charge in 2.5 hours
- Runs for 40 minutes on high speed and 90 minutes on low speed



SILICONE



**MATERIALS:** Silicone (massager, button, charging port)  
ABS with PU Cote (base)

### MEASUREMENTS:

3" x 1.5"/7.5 cm x 3.75 cm (shaft)  
2" x 1"/5 cm x 2.5 cm (stimulator)  
6" x 1.5"/15.25 cm x 3.75 cm (overall)

### CHARGING INFORMATION:

LED light will flash while charging and glow solid when fully charged. Fully charge product before use. Battery life depends on frequency and speed of use. We recommend fully charging your product once every 6 months. Complete charge time: 2.5 hours; Run time on high: 40 minutes; Run time on low: 90 minutes.

### OPERATING INSTRUCTIONS:

1. This item comes with a travel lock feature. To turn product on, press and hold the power button for 3 seconds.
2. Continue to press button until the desired speed is reached.
3. To turn product off, repeat step 1.
4. This item comes with a memory feature; item will resume on last speed used.