

ENDLESS SUMMER™ SUNSET SEDUCER



FEATURES:

- Glow with desire!
- Powerful massager with angled head for enhanced pleasure
- Flexible shaft with extremely pliable design
- 10 speeds of intense vibration
- Radiant LED light changes with speed
- Dual layer Liquid Silicone: softer, smoother, durable, and waterproof
- State-of-the-art memory chip resumes on last speed used
- Security travel lock feature – hold for 3 seconds to turn on or off
- USB rechargeable – charging cord included
- Complete charge in 2.5 hours
- Runs for 40 minutes on high speed and 90 minutes on low speed



MATERIALS: Silicone

MEASUREMENTS:

5.25" x 1.25"/13.25 cm x 3.25 cm (insertable)
7" x 1.25"/17.75 cm x 3.25 cm (overall)

CHARGING INFORMATION:

LED light will flash while charging and glow solid when fully charged. Fully charge product before use. Battery life depends on frequency and speed of use. We recommend fully charging your product once every 6 months.

OPERATING INSTRUCTIONS:

1. This item comes with a travel lock feature. To turn product on, press and hold the power button for 3 seconds.
2. Press the button repeatedly until the desired speed is reached.
3. To turn product off, press and hold the power button for 3 seconds.
4. This item comes with a memory feature; item will resume on last speed used.

- This product is intended for adult use only. Keep out of reach of children.
 - Stop use immediately if you experience pain, discomfort, or irritation.
 - Clean the product before and after each use.
 - Use water-based lubricants to ease application and prevent friction.
 - Avoid silicone-based lubricants, which may damage the product surface.
 - Store in a cool, dry place, away from direct sunlight or excessive heat.
 - Use only the charging cable provided or a compatible certified cable.
 - Read and follow all instructions provided with the product prior to first use.
-

- Ce produit est réservé aux adultes. Tenir hors de portée des enfants.
 - Cessez immédiatement l'utilisation en cas de douleur, d'inconfort ou d'irritation.
 - Nettoyez le produit avant et après chaque utilisation.
 - Utilisez un lubrifiant à base d'eau pour faciliter l'application et éviter les frottements.
 - Évitez les lubrifiants à base de silicone, qui peuvent endommager la surface du produit.
 - Conservez le produit dans un endroit frais et sec, à l'abri de la lumière directe du soleil et des sources de chaleur excessive.
 - Utilisez uniquement le câble de chargement fourni ou un câble certifié compatible.
 - Lisez attentivement et suivez toutes les instructions fournies avec le produit avant la première utilisation.
-

- Este producto está diseñado solo para adultos. Manténgalo fuera del alcance de los niños.
 - Suspenda su uso inmediatamente si experimenta dolor, molestias o irritación.
 - Limpie el producto antes y después de cada uso.
 - Use lubricantes a base de agua para facilitar la aplicación y evitar la fricción.
 - Evite los lubricantes a base de silicona, ya que pueden dañar la superficie del producto.
 - Guárdelo en un lugar fresco y seco, alejado de la luz solar directa y del calor excesivo.
 - Utilice únicamente el cable de carga incluido o un cable certificado compatible.
 - Lea y siga todas las instrucciones incluidas con el producto antes del primer uso.
-

- Dieses Produkt ist nur für Erwachsene bestimmt. Außerhalb der Reichweite von Kindern aufbewahren.
- Die Anwendung sofort abbrechen, wenn Schmerzen, Unbehagen oder Reizungen auftreten.
- Reinigen Sie das Produkt vor und nach jeder Anwendung.
- Verwenden Sie Gleitmittel auf Wasserbasis, um die Anwendung zu erleichtern und Reibung zu vermeiden.
- Vermeiden Sie Gleitmittel auf Silikonbasis, da diese die Produktoberfläche beschädigen können.
- Lagern Sie das Produkt kühl und trocken, vor direkter Sonneneinstrahlung und übermäßiger Hitze geschützt.
- Verwenden Sie ausschließlich das mitgelieferte Ladekabel oder ein kompatibles, zertifiziertes Kabel.
- Lesen und befolgen Sie vor der ersten Verwendung alle dem Produkt beiliegenden Anweisungen.